

KNX Choke

ENG - Data sheet

Issue date 5.06.2013

Application

The choke decouples the KNX/EIB bus line from the power line. Choke can be used in any KNX/EIB installation where high reliability is required. Choke supports 4 external powering mechanisms. If one of power sources gets broken, the Choke automatically will switch to backup power source. Moreover there is interruptible switch between power sources, overcurrent and overvoltage protection, PSU filters (noise and backup) especially created to work with impulse load.

Choke is able to charge 24V battery if its connected and there is standard 24V output for powering external devices like Logic Machine.



Types of product

CHOKE-KNX KNX/EIB Choke

Standards and norms compliance

CE conformity:	EMBS-CE-110124/01	Electromagnetic compatibility
EMC:	EN61000-6-1 EN61000-6-3	

Technical data:

Power supply input:	4	3 x 18-28V DC power supplies supported; 1 x 24V accumulator with charging possibility
Power supply output	1	24V for powering external

devices

Power redundancy	If one fails, others automatically overtakes the operation	
Battery charging	Voltage drop for battery charging is 2V from input voltage	
Max. current on power supply	750 mA	
Power consumption:	< 20 mA	
Interface:	2	KNX/EIB
Clamps:	Power supply: KNX/EIB bus:	1.5mm ² 1.5mm ²
Enclosure:	Material: Color: Dimensions:	Polyamide Gray 52(W)x90(H)x51(L) mm
Usage temperature:	-5C ... +55C	
Storage temperature:	-20C ... +70C	
Weight:	100g	



Caution Security advice

The installation and assembly of electrical equipment may only be performed by skilled electrician. The devices must not be used in any relation with equipment that supports, directly or indirectly, human health or life or with application that can result danger of people, animals or real value

Mounting advice

The devices are supplied in operational status. The cables connections included can be clamped to the housing if required.

Electrical connection

The devices are constructed for the operation of protective low voltage (SELV). Grounding of device not needed. When switching the power supply on or off, power surges must be avoided.

Terminal connection scheme

